

BAFFLE INSTALLATION INSTRUCTIONS:

1. BOTH BAFFLES MUST BE ALIGNED VERTICALLY AT THE SAME RU PLACEMENT OF EQUIPMENT
 - THE **LEFT** SIDE BAFFLE IS THE **EXHAUST** SIDE (CLOSED FACE TOWARD THE FRONT OF ENCLOSURE)
 - THE **RIGHT** SIDE BAFFLE IS THE **INTAKE** SIDE (CLOSED FACE TOWARD THE REAR OF ENCLOSURE)

2. EXHAUST BAFFLE (LEFT SIDE):

- A. USE QTY. 2 PLASTIC RIVETS TO ATTACH THE **CLOSED** FACE OF THE BAFFLE TO THE **FRONT, OUTSIDE** OF THE FRONT VERTICAL POST
- B. USE QTY. 4 PLASTIC RIVETS TO FIX THE **OPPOSITE, OPEN** SIDE OF THE BAFFLE TO THE **SIDE** OF THE REAR VERTICAL POST

3. INTAKE BAFFLE (RIGHT SIDE):

- A. USE QTY. 4 PLASTIC RIVETS TO ATTACH THE **OPEN** SIDE OF BAFFLE TO THE **SIDE** OF THE FRONT VERTICAL POST
- B. USE QTY. 2 #10-32 SCREWS TO FIX THE **CLOSED** FACE OF THE BAFFLE TO THE **OUTSIDE FACE** OF THE REAR VERTICAL POST
 - NOTE: PLASTIC FINGERS MAY NEED TO BE REMOVED ON THE RIGHT REAR POST AND THEN RE-INSTALLED WITH #10-32 SCREWS AFTER BAFFLE IS IN LOCATION

4. TOP /BOTTOM COVERS ON BOTH SIDES:

- A. PIVOT TOP/BOTTOM COVERS BEHIND FRONT POSTS AND USE 4 PLASTIC RIVETS TO ATTACH
 - INSTALL QTY. 2 PLASTIC RIVET INTO INSIDE FACES OF THE FRONT AND REAR VERTICAL POSTS
 - INSTALL QTY. 2 PLASTIC RIVETS INTO TOP/BOTTOM OF BAFFLE PER COVER
- B. WHEN INSTALLING NOTE REMOVEABLE NOTCHES IN REAR OF COVERS. COVERS MAY NEED TO BE NOTCHED TO ACCOMODATE FOR YOUR SPECIFIC REAR RAIL PLACEMENT
- C. REPEAT STEP A IN TWO PLACES ON THE TOP AND BOTTOM, FOR BOTH INTAKE AND EXHAUST BAFFLES

